



491 W. Garfield Ave., Coldwater, MI 49036

Phone: 517-279-2135

Web/live chat: www.bds-suspension.com

E-mail: tech@bds-suspension.com

Part#: **014251, 014252, 014253**

Product: **Box Kit**

Application: **Jeep CJ5, CJ6, M38A1**

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

PRODUCT SAFETY WARNING Certain BDS Suspension products are intended to improve off-road performance. Modifying your vehicle for off-road use may result in the vehicle handling differently than a factory equipped vehicle. Extreme care must be used to prevent loss of control or vehicle rollover. Failure to drive your modified vehicle safely may result in serious injury or death. BDS Suspension Co. does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your modified vehicle under the influence of alcohol or drugs. Always drive your modified vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Always wear your seat belt.

PRE-INSTALLATION NOTES

1. Special literature required: OE Service Manual for model/year of vehicle. Refer to manual for proper disassembly/ reassembly procedures of OE and related components.
2. Adhere to recommendations when replacement fasteners, retainers and keepers are called out in the OE manual.
3. Larger rim and tire combinations may increase leverage on suspension, steering, and related components. When selecting combinations larger than OE, consider the additional stress you could be inducing on the OE and related components.
4. Post suspension system vehicles may experience drive line vibrations. Angles may require tuning, slider on shaft may require replacement, shafts may need to be lengthened or trued, and U-joints may need to be replaced.
5. Secure and properly block vehicle prior to installation of BDS Suspension components. Always wear safety glasses when using power tools.
6. If installation is to be performed without a hoist, BDS Suspension Co. recommends rear alterations first.
7. Due to payload options and initial ride height variances, the amount of lift is a base figure. Final ride height dimensions may vary in accordance to original vehicle attitude. Always measure the attitude prior to beginning installation.

POST-INSTALLATION WARNINGS

1. Check all fasteners for proper torque. Check to ensure for adequate clearance between all rotating, mobile, fixed, and heated members. Verify clearance between exhaust and brake lines, fuel lines, fuel tank, floor boards and wiring harness. Check steering gear for clearance. Test and inspect brake system.
2. Perform steering sweep to ensure front brake hoses have adequate slack and do not contact any rotating, mobile or heated members. Inspect rear brake hoses at full extension for adequate slack. Failure to perform hose check/ replacement may result in component failure. Longer replacement hoses, if needed can be purchased from a local parts supplier.
3. Perform head light check and adjustment.
4. Re-torque all fasteners after 500 miles. Always inspect fasteners and components during routine servicing.

PARTS LIST

Part #	Qty	Description	014251	014252	014253
		Description			
		1/2 x 2-1/2 x 7" U-Bolt	3	3	3
		1/2 x 2-3/4 x 6-1/2" U-Bolt	5	1	
		1/2 x 3 x 6-3/4" U-Bolt		4	4
		1/2 x 3-1/4 x 7" U-Bolt			1

INSTALLATION INSTRUCTIONS

Front Installation

1. Raise vehicle and place jack stands under frame a few inches behind front spring. Remove wheels and shocks.
2. Place a hydraulic jack under the front axle. Remove u-bolts holding the OE leaf pack to the axle. New u-bolts are supplied. Raise the jack/axle to allow spring removal. Remove the springs shackle and stationary eye bolts and remove springs.
3. The #004252 is the front spring. Install it so the numbered end of the spring is forward. Using OE bolts and shackles, mount spring to frame but do not torque bolts at this time.
4. Clean the spring-to-axle mating points. Lower jack/axle onto the springs. **Caution: Do not over extend the OE brake lines. Be sure center bolt heads align and seat properly into the spring perch holes.**
5. Position u-bolt plates and install u-bolts using supplied flat washers and nuts. Torque u-bolts to 75-85 ft-lbs.
6. Install BDS shocks. Install tires and wheels.
7. With suspension unloaded and hanging, cycle steering lock to lock, while manually spinning wheels and inspect steering, suspension, and drive line for proper operation, clearances, and lengths. Pay close attention to brake and axle vent hoses.
8. Remove jack stands and lower vehicle to ground. Torque shackle bolts and hanger bolts to 45 ft.lbs. Block front tires.

ⓘ Note: At this point, to prolong the life of your springs, BDS Suspension recommends replacing OEM bump stop with longer aftermarket bump stops.

Rear Installation

9. Raise rear of vehicle and support with jack stands under frame a few inches in front of the rear springs stationary eyes. Remove wheels and shocks. Lower vehicle onto jack stands.
10. Place a hydraulic jack under the axle. Remove u-bolts. New u-bolts are supplied. Raise the jack/axle to allow spring removal. Remove the springs shackle and stationary eye bolts and remove springs.
11. The #004258 is the rear spring. Install it so the numbered end of the spring is forward. Using OE bolts and shackles mount spring to frame but do not torque bolts at this time.
12. Clean the spring-to-axle mating points. Lower jack/axle onto the springs. **Caution: Do not over extend the OE brake lines. Be sure center bolt heads align and seat properly into the spring perch holes.**
13. Position u-bolt plates and install u-bolts. Torque to 75-85 ft-lbs.
14. Install BDS shock absorbers. Install tires and wheels.
15. With suspension unloaded and hanging, while manually spinning wheels, inspect suspension, and drive line for proper operation, clearances, and lengths. Pay close attention to brake and axle vent hoses.
16. Remove jack stands and lower vehicle to ground. Torque shackle bolts and hanger bolts to 45 ft.lbs.

ⓘ Note: At this point, to prolong the life of your springs, BDS Suspension recommends replacing OEM bump stop with longer aftermarket bump stops.

Alignment angles will be effected by installation of a suspension lift. We suggest an alignment be performed to ensure proper handling and tire wear.