

**50-inch Straight LED Light Bar
Upper Windshield Mounting Brackets
Nissan: Titan 4WD/2WD**

Parts:

1 - Driver Side Bracket
1 - Passenger Side Bracket
2 - Rubber Spacer Pads
4 - 5/16" Button-head Bolts
4 - Nut Inserts
4 - 5/16"x1" Bolts, Washers and 3/8" Nuts

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any after-market devices. Any and all claims implied in this document excluded.

NOTES:

Light bar not included in kit. Fits straight LED light bar 50 3/16" long from mount point to mount point.

REQUIRED TOOLS:

1/2" Wrench	9/16" Wrench	3/16" Allen Wrench	Center Drill	33/64" Drill Bit
Tape Measure	Permanent Marker	Anti-Seize		

INSTALLATION INSTRUCTIONS

STEP 1: Disconnect positive battery lead before installation.

STEP 2: On driver side, measure 2 1/2" from top of windshield seal to front edge of bracket.

STEP 3: Mark bracket location.

STEP 4: Drill two holes in channel with 33/64" drill bit. DO NOT drill any deeper than 1/2" or you may damage the inside surface.

STEP 5: Assemble nut inserts. Place washer on 5/16" x 1" bolt, then thread on 3/8" nut. Thread bolt (with nut and washer) into nut insert. Place assembly into hole in door frame.

STEP 6: Hold nut in place with 9/16" wrench and tighten bolt with 1/2" wrench to compress insert and hold it in place.

STEP 7: Repeat for both nut inserts.

STEP 8: Place rubber spacer pad on bottom of bracket.

STEP 9: Hold bracket in place and line up mounting holes. Secure with included 5/16" button-head bolts. Use small amount of anti-seize on threads and tighten with 3/16" allen wrench.

STEP 10: Repeat steps on passenger side.

STEP 11: Install light bar and wire power per instructions supplied with kit.

STEP 12: Reconnect positive battery lead.

POST-INSTALLATION

MAINTENANCE: Periodically check to ensure that all fasteners are properly tightened.